


5.




After the installation, turn on the switch and check for leakage (if there is leakage at the threaded tube, unscrew it and continue to add seal tape).

Installation Manual


B01-BPF01

Installation and Usage Instruction




Box Contents


No.	Items	Qty
1.	Faucet	1
2.	Base	1
3.	Thread Seal Tape	1
4.	Hexagon Key	1
5.	Instruction Manual	1



Product Dimension (in mm)




1.




Open the package and take out the tap and base.

2.




Put the base on the faucet's thread tube.

3.



Take out the seal tape and wrap it around the thread tube, wrap it a few more times.

4.



Tighten the thread tube on the faucet clockwise into the reserved installation hole, and adjust it after tightening.